Thank you for your Unger purchase!

PROFESSIONAL UNGER

RINSE 'N' GO PLUS™

QUICK-START GUIDE

READ THIS FIRST

Contents under pressure.
Can cause severe injury or death from tank rupture.
This Quick-Start User Guide is not a substitute for reading the User Manual. To reduce the risk of injury or death, user must read and understand the User Manual before using this product. This product is not intended for commercial use. It is intended for residential application only.

Let's get started!



1. Connect the included connectors and hose to water source
2. Connect water source hose to inlet connection at the bottom of unit



3. Connect garden hose and connectors to outlet connection at top of unit
4. Connect the Soap Blasting Nozzle and start flow of water through the system, you are now ready to wash your vehicle!

DO NOT REMOVE RESIN FROM NYLON BAG

Unger recommends washing your car in the shade. Washing your car under the hot sun will cause the soap to dry fast and potentially settle on the car. If this can't be avoided, be sure to keep the soap areas wet until ready to rinse it off.

HOW TO WASH YOUR CAR USING RINSE 'N' GO PLUS

- Wash your car as you normally would to remove dirt and grime. The Soap Blasting Car Wash Nozzle is a fast way to soap up your car.
- Using the Rinse 'n' Go Plus system, rinse car with pure (deionized) water. Make sure to rinse every part of the car, including areas where soap might get stuck such as trunk, fuel door, and lights.
- For best results, rinse the car twice to remove all soap. You are done! No need to dry your car.

The pure water from the Rinse 'N' Go Plus system does all the work for you so that your car will dry completely spot-free! Just like if you had it cleaned at a professional car wash.

IMPORTANT WARNINGS (SEE USER MANUAL FOR FULL LIST OF WARNINGS)

- Until water is flowing out of system, keep water outlet open or press yellow pressure release button down to remove trapped air from system.
- Do not exceed water pressure of 90 psi.
- Do not connect to pressure washer or auxiliary pump.
- Inspect system and any attachments for leaks, cracks, or dents.
- Be sure cover is in fully locked position.
- For use only with tap water.

Your satisfaction is important

For help with assembly or product information please call us, we are here to help.
1 (800) 833-6100 Monday – Friday 8:30 AM – 5:00 PM EST (excluding major holidays)
or you can email: retailcustomercare@ungerglobal.com
DO NOT RETURN TO STORE, CALL US FIRST.
Our Rinse 'N' Go Plus Customer Support will assist you.